

# Color Analysis of Floral Tissues

K. Uckele

2025-02-06

## Contents

<b>Introduction</b>	<b>2</b>
<b>Setup</b>	<b>2</b>
Load Required Libraries . . . . .	2
Set working directory . . . . .	3
Define Custom Operators . . . . .	3
Authenticate Google Sheets Access . . . . .	3
<b>Quality Control</b>	<b>3</b>
Load Spectral Data from Google Sheets . . . . .	3
<b>Full Spectrum Analyses</b>	<b>4</b>
Spectral Data Processing . . . . .	4
Convert Data to rspec Objects . . . . .	4
Average the Spectra . . . . .	4
Fix Negative Reflectance Values . . . . .	6
Determine Smoothing Parameter . . . . .	7
Smooth the Spectral Data . . . . .	7
Scale the Spectral Data . . . . .	8
Plot Processed Spectra . . . . .	8
Define Common Plotting Parameters . . . . .	8
Bract Spectra Plot . . . . .	8
Petal Spectra Plot . . . . .	9
Labellum Spectra Plot . . . . .	10
Combine and Save Spectral Plots with Highlighted Parents . . . . .	11
Principal component analysis - Bract . . . . .	12
Principal component analysis - Petal . . . . .	15
Principal component analysis - Labellum . . . . .	18
Format PC Scores . . . . .	21
Spectral Descriptors . . . . .	21
Define spectral descriptors . . . . .	21
Calculate Spectral Descriptors . . . . .	21
Bract . . . . .	21
Plot Bract Spectral Descriptors Histograms . . . . .	21
Petal Summary . . . . .	22
Plot Petal Spectral Descriptors Histograms . . . . .	22
Labellum Summary . . . . .	23
Plot Labellum Spectral Descriptors Histograms . . . . .	23
Data Formatting and Export . . . . .	24
Reformat Rownames . . . . .	24
Subset and Rename Columns . . . . .	25

Convert Rownames to a Column . . . . .	25
<b>UV Analyses</b>	<b>25</b>
Spectral Data Processing . . . . .	25
Convert Data to rspec Objects . . . . .	25
Average the Spectra . . . . .	26
Fix Negative Reflectance Values . . . . .	28
Determine Smoothing Parameter . . . . .	28
Smooth the Spectral Data . . . . .	29
Scale the Spectral Data . . . . .	29
Plot Processed Spectra . . . . .	30
Define Common Plotting Parameters . . . . .	30
Bract Spectra Plot . . . . .	30
Petal Spectra Plot . . . . .	31
Labellum Spectra Plot . . . . .	32
Combine and Save Spectral Plots with Highlighted Parents . . . . .	33
Spectral Descriptors . . . . .	34
Define spectral descriptors . . . . .	34
Calculate Spectral Descriptors . . . . .	34
Bract . . . . .	34
Plot Bract Spectral Descriptors Histograms . . . . .	34
Petal Summary . . . . .	35
Plot Petal Spectral Descriptors Histograms . . . . .	36
Labellum Summary . . . . .	36
Plot Labellum Spectral Descriptors Histograms . . . . .	37
Data Formatting and Export . . . . .	38
Reformat Rownames . . . . .	38
Convert Rownames to a Column . . . . .	38
Subset and Rename Columns . . . . .	38
<b>Vision Models</b>	<b>38</b>
<b>Merge Dataframes</b>	<b>43</b>
<b>Export Summary Descriptors to CSV</b>	<b>43</b>

## Introduction

This analysis explores the color properties of different floral tissues — bract, petal, and labellum — using spectral data sourced from Google Sheets. The analysis includes data loading, quality control, spectral processing, visualization, and the computation of summary descriptors.

## Setup

### Load Required Libraries

```
## libraries
library(googleheets4)
library(cowplot)
library(dplyr)

##
## Attaching package: 'dplyr'
```

```
## The following objects are masked from 'package:stats':
##
##   filter, lag
## The following objects are masked from 'package:base':
##
##   intersect, setdiff, setequal, union
library(tibble)
library(knitr)
library(rmarkdown)
library(pavo)
```

## Set working directory

```
# Set the root directory to the project root
knitr::opts_knit$set(root.dir = normalizePath("../"))
```

## Define Custom Operators

```
# Define a 'not in' operator
`%notin%` = Negate(`%in%`)
```

## Authenticate Google Sheets Access

Authenticate access to Google Sheets using your email. Ensure that the email has the necessary permissions to access the sheets.

```
# Authenticate with Google Sheets
gs4_auth(email = "kuckele@ucsc.edu")
```

## Quality Control

### Load Spectral Data from Google Sheets

We load the spectral data for bract, petal, and labellum from the specified Google Sheets.

```
# Specify the Google Sheets ID
sheet_id <- "12NWt1qKbLPaXU-rVBTqMQjY_6jH1DulVvNHS_QXAvFI"
```

```
# Load data for different floral tissues
bract <- read_sheet(ss = sheet_id, sheet = "Bract")
```

```
## v Reading from "Color".
```

```
## v Range "'Bract'".
```

```
petal <- read_sheet(ss = sheet_id, sheet = "Petal")
```

```
## v Reading from "Color".
```

```
## v Range "'Petal'".
```

```
labellum <- read_sheet(ss = sheet_id, sheet = "Labellum")
```

```
## v Reading from "Color".
```

```
## v Range "'Labellum'".
```

# Full Spectrum Analyses

## Spectral Data Processing

### Convert Data to rspec Objects

The spectral data is converted into rspec objects using the pavo package for further analysis.

```
# Set seed for reproducibility
set.seed(1612217)

# Convert datasets to rspec objects with wavelength limits
bract_spec <- as.rspec(bract, lim = c(300, 700), whichwl = 1)

## The spectral data contain 555 negative value(s),
## which may produce unexpected results if used in models.
## Consider using procspec() to correct them.

petal_spec <- as.rspec(petal, lim = c(300, 700), whichwl = 1)

## The spectral data contain 272 negative value(s),
## which may produce unexpected results if used in models.
## Consider using procspec() to correct them.

labellum_spec <- as.rspec(labellum, lim = c(300, 700), whichwl = 1)

# change column names
colnames(bract_spec) <- gsub("-", "x", colnames(bract_spec))
colnames(petal_spec) <- gsub("-", "x", colnames(petal_spec))
colnames(labellum_spec) <- gsub("-", "x", colnames(labellum_spec))
```

Note: The conversion may produce warnings about negative values in spectral data, which are addressed in subsequent steps.

### Average the Spectra

Aggregate the spectral data by sample names, averaging replicates.

```
# Extract sample names by removing trailing numbers in parentheses
bract_samples <- gsub("\\([0-9]+\\)", "", names(bract_spec))[-1]
petal_samples <- gsub("\\([0-9]+\\)", "", names(petal_spec))[-1]
labellum_samples <- gsub("\\([0-9]+\\)", "", names(labellum_spec))[-1]

# Verify sample counts
table(bract_samples)

## bract_samples
##      125      126      39 39x10 39x109 39x110 39x115 39x116 39x117 39x12 39x122
##         2         3         1         2         1         2         2         1         3         2         2
## 39x123 39x125 39x126 39x13 39x130 39x136 39x14 39x15 39x16 39x17 39x2
##         2         2         2         1         3         2         3         2         4         2         2
## 39x21 39x23 39x25 39x27 39x34 39x39 39x4 39x40 39x41 39x44 39x46
##         2         2         2         2         2         2         2         2         2         2         2
## 39x49 39x50 39x51 39x55 39x56 39x57 39x6 39x60 39x65 39x67 39x68
##         2         2         2         2         2         2         2         2         2         2         1
## 39x75 39x77 39x78 39x79 39x8 39x81 39x82 39x86 39x87 39x89 39x92
##         2         2         2         2         1         2         3         1         1         2         2
## 39x93 39x95 39x96 39x98 62x10 62x103 62x105 62x109 62x116 62x119 62x122
```

```
##      2      2      2      2      1      2      2      1      1      2      1
## 62x125 62x128 62x129 62x13 62x130 62x131 62x134 62x135 62x136 62x137 62x138
##      1      1      2      2      1      2      1      2      2      1      1
## 62x139 62x14 62x140 62x143 62x144 62x147 62x151 62x152 62x153 62x154 62x157
##      1      1      2      1      2      1      1      3      2      2      2
## 62x158 62x16 62x162 62x167 62x168 62x169 62x17 62x172 62x173 62x175 62x18
##      2      2      2      2      1      1      2      2      2      2      1
## 62x182 62x185 62x188 62x189 62x19 62x190 62x197 62x200 62x206 62x21 62x214
##      1      2      1      1      2      2      2      2      2      2      1
## 62x218 62x219 62x22 62x220 62x225 62x233 62x234 62x240 62x251 62x252 62x258
##      2      2      2      1      2      1      1      2      2      1      1
## 62x261 62x264 62x265 62x267 62x268 62x276 62x282 62x293 62x296 62x300 62x302
##      2      2      1      2      2      1      1      2      1      1      1
## 62x303 62x304 62x305 62x306 62x307 62x308 62x309 62x310 62x313 62x315 62x322
##      2      1      1      1      2      1      2      1      1      1      1
## 62x324 62x327 62x332 62x337 62x338 62x351 62x355 62x359 62x363 62x370 62x5
##      1      1      2      1      2      1      2      2      2      1      1
## 62x57 62x58 62x59 62x60 62x63 62x65 62x66 62x69 62x73 62x74 62x75
##      2      2      2      1      1      1      1      2      2      1      1
## 62x77 62x83 62x87 62x91 62x92 62x94 62x96 BRAC
##      1      2      1      2      2      1      1      2
```

```
table(petal_samples)
```

```
## petal_samples
##      125      126      39 39x10 39x109 39x110 39x115 39x116 39x117 39x12 39x122
##      2      2      1      2      1      2      2      1      3      2      2
## 39x123 39x125 39x126 39x13 39x130 39x136 39x14 39x15 39x16 39x17 39x2
##      2      2      2      1      3      2      3      2      4      2      2
## 39x21 39x23 39x25 39x27 39x34 39x39 39x4 39x40 39x41 39x44 39x46
##      2      2      2      2      2      2      2      2      2      2      2
## 39x49 39x50 39x51 39x55 39x56 39x57 39x6 39x60 39x65 39x67 39x68
##      2      2      2      2      2      2      2      2      2      2      1
## 39x75 39x77 39x78 39x79 39x8 39x81 39x82 39x86 39x87 39x89 39x92
##      2      2      2      2      1      2      3      1      1      2      2
## 39x93 39x95 39x96 39x98 62x10 62x103 62x105 62x109 62x116 62x119 62x122
##      2      2      2      2      1      2      2      1      1      2      1
## 62x125 62x128 62x129 62x13 62x130 62x131 62x134 62x135 62x136 62x137 62x138
##      1      1      2      2      1      2      1      2      2      1      1
## 62x139 62x14 62x140 62x143 62x144 62x147 62x151 62x152 62x153 62x154 62x157
##      1      1      2      1      2      1      1      3      2      2      2
## 62x158 62x16 62x162 62x167 62x168 62x169 62x17 62x172 62x173 62x175 62x18
##      2      2      2      2      1      1      2      2      2      2      1
## 62x182 62x185 62x188 62x189 62x19 62x190 62x197 62x200 62x206 62x21 62x214
##      1      2      1      1      2      2      2      2      2      2      1
## 62x218 62x219 62x22 62x220 62x225 62x233 62x234 62x240 62x251 62x252 62x258
##      2      2      2      1      2      1      1      2      2      1      1
## 62x261 62x262 62x264 62x265 62x268 62x276 62x282 62x293 62x296 62x300 62x302
##      2      2      2      1      2      1      1      2      1      1      1
## 62x303 62x304 62x305 62x306 62x307 62x308 62x309 62x310 62x313 62x315 62x322
##      2      1      1      1      2      1      2      1      1      1      1
## 62x324 62x327 62x332 62x337 62x338 62x351 62x355 62x359 62x363 62x370 62x5
##      1      1      2      1      2      1      2      2      2      1      1
## 62x57 62x58 62x59 62x60 62x63 62x65 62x66 62x69 62x73 62x74 62x75
##      2      2      2      1      1      1      1      2      2      1      1
```

```
## 62x77 62x83 62x87 62x91 62x92 62x94 62x96 BRAC
##      1      2      1      2      2      1      1      2
```

```
table(labellum_samples)
```

```
## labellum_samples
##      125      126      39 39x10 39x109 39x110 39x115 39x116 39x117 39x12 39x122
##      2      2      1      2      1      2      2      1      3      2      2
## 39x123 39x125 39x126 39x13 39x130 39x136 39x14 39x15 39x16 39x17 39x2
##      2      2      2      1      3      2      3      2      4      2      2
## 39x21 39x23 39x25 39x27 39x34 39x39 39x4 39x40 39x41 39x44 39x46
##      2      2      2      2      2      2      2      2      2      2      2
## 39x49 39x50 39x51 39x55 39x56 39x57 39x6 39x60 39x65 39x67 39x68
##      2      2      2      2      2      2      2      2      2      2      1
## 39x75 39x77 39x78 39x79 39x8 39x81 39x82 39x86 39x87 39x89 39x92
##      2      2      2      2      1      2      3      1      1      2      2
## 39x93 39x95 39x96 39x98 62x10 62x103 62x105 62x109 62x116 62x119 62x122
##      2      2      2      2      1      2      2      1      1      2      1
## 62x125 62x128 62x129 62x13 62x130 62x131 62x134 62x135 62x136 62x137 62x138
##      1      1      2      2      1      2      1      2      2      1      1
## 62x139 62x14 62x140 62x143 62x144 62x147 62x151 62x152 62x153 62x154 62x157
##      1      1      2      1      2      1      1      3      2      2      2
## 62x158 62x16 62x162 62x167 62x168 62x169 62x17 62x172 62x173 62x175 62x18
##      2      2      2      2      1      1      2      2      2      2      1
## 62x182 62x185 62x188 62x189 62x19 62x190 62x197 62x200 62x206 62x21 62x214
##      1      2      1      1      2      2      2      2      2      2      1
## 62x218 62x219 62x22 62x220 62x225 62x233 62x234 62x240 62x251 62x252 62x258
##      2      2      2      1      2      1      1      2      2      1      1
## 62x261 62x262 62x264 62x265 62x268 62x276 62x282 62x293 62x296 62x300 62x302
##      2      2      2      1      2      1      1      2      1      1      1
## 62x303 62x304 62x305 62x306 62x307 62x308 62x309 62x310 62x313 62x315 62x322
##      2      1      1      1      2      1      2      1      1      1      1
## 62x324 62x327 62x332 62x337 62x338 62x351 62x355 62x359 62x363 62x370 62x5
##      1      1      2      2      2      1      2      2      2      1      1
## 62x57 62x58 62x59 62x60 62x63 62x65 62x66 62x69 62x73 62x74 62x75
##      2      2      2      1      1      1      1      2      2      1      1
## 62x77 62x83 62x87 62x91 62x92 62x94 62x96 BRAC
##      1      2      1      2      2      1      1      2
```

```
# Aggregate spectra by sample names using mean
bract_spec_avg <- aggspec(bract_spec, by = bract_samples, FUN = mean)
petal_spec_avg <- aggspec(petal_spec, by = petal_samples, FUN = mean)
labellum_spec_avg <- aggspec(labellum_spec, by = labellum_samples, FUN = mean)
```

## Fix Negative Reflectance Values

Negative reflectance values are corrected by adding the minimum reflectance.

```
# Fix negative values by adding the minimum reflectance
bract_spec_avg <- procspec(bract_spec_avg, fixneg = "admin")
```

```
## processing options applied:
```

```
## Negative value correction: added min to all reflectance
```

```
petal_spec_avg <- procspec(petal_spec_avg, fixneg = "admin")
```

```
## processing options applied:
```


```
## Negative value correction: added min to all reflectance
labellum_spec_avg <- procspec(labellum_spec_avg, fixneg = "admin")
```

```
## processing options applied:
## Negative value correction: added min to all reflectance
```

## Determine Smoothing Parameter

Use `plotsmooth` to visualize and decide on an appropriate smoothing span.

```
# Plot to determine suitable smoothing span
plotsmooth(bract_spec_avg[,1:7],
  minsmooth = 0.05,
  maxsmooth = 0.5,
  curves = 4,
  ask = FALSE)
```



Choose a span (e.g., 0.2) based on the plot to balance smoothness and data fidelity.

## Smooth the Spectral Data

Apply smoothing to the spectral data using the chosen span.

```
# Apply smoothing with span = 0.2
bract_spec_sm <- procspec(bract_spec_avg, opt = "smooth", span = 0.2)
```

```
## processing options applied:
## smoothing spectra with a span of 0.2
```

```
petal_spec_sm <- procspec(petal_spec_avg, opt = "smooth", span = 0.2)

## processing options applied:
## smoothing spectra with a span of 0.2

labellum_spec_sm <- procspec(labellum_spec_avg, opt = "smooth", span = 0.2)

## processing options applied:
## smoothing spectra with a span of 0.2
```

## Scale the Spectral Data

Scale the spectral data to different reference points for comparative analysis.

```
# Scale spectra to both minimum and maximum reflectance
bract_spec_scaleminmax <- procspec(bract_spec_sm, opt = c("min", "max"))

## processing options applied:
## Scaling spectra to a minimum value of zero
## Scaling spectra to a maximum value of 1

petal_spec_scaleminmax <- procspec(petal_spec_sm, opt = c("min", "max"))

## processing options applied:
## Scaling spectra to a minimum value of zero
## Scaling spectra to a maximum value of 1

labellum_spec_scaleminmax <- procspec(labellum_spec_sm, opt = c("min", "max"))

## processing options applied:
## Scaling spectra to a minimum value of zero
## Scaling spectra to a maximum value of 1
```

## Plot Processed Spectra

Visualize the processed spectral data for each floral tissue, highlighting specific samples.

## Define Common Plotting Parameters

```
# Define a color palette for highlighting specific samples
highlight_colors <- c(rep("lightgrey", 170), "gold1", "gold1", "darkgreen")
```

## Bract Spectra Plot

```
# Order samples to highlight specific ones
order_spec_bract <- c(
  which(names(bract_spec_scaleminmax) == "125"),
  which(names(bract_spec_scaleminmax) == "126"),
  which(names(bract_spec_scaleminmax) == "BRAC")
)

# Reorder columns to place highlighted samples at the end
columns_bract <- 1:ncol(bract_spec_scaleminmax)
order_spec_bract <- c(columns_bract[columns_bract %notin% order_spec_bract], order_spec_bract)


# Plot the spectra
```



```
plot(bract_spec_scaleminmax[order_spec_bract], type = "o",
     col = highlight_colors, main = "Bract Spectra",
     xlab = "Wavelength (nm)", ylab = "Reflectance (%)")

# Add a legend
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
      col = c("darkgreen", "gold1"), lty = 1, cex = 0.8)
```

## Bract Spectra



## Petal Spectra Plot

```
# Order samples to highlight specific ones
order_spec_petal <- c(
  which(names(petal_spec_scaleminmax) == "125"),
  which(names(petal_spec_scaleminmax) == "126"),
  which(names(petal_spec_scaleminmax) == "BRAC")
)


# Reorder columns to place highlighted samples at the end
columns_petal <- 1:ncol(petal_spec_scaleminmax)
order_spec_petal <- c(columns_petal[columns_petal %notin% order_spec_petal], order_spec_petal)

# Plot the spectra
plot(petal_spec_scaleminmax[order_spec_petal], type = "o",
     col = highlight_colors, main = "Petal Spectra",
     xlab = "Wavelength (nm)", ylab = "Reflectance (%)")

# Add a legend
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
```

```
col = c("darkgreen", "gold1"), lty = 1, cex = 0.8)
```

## Petal Spectra



## Labellum Spectra Plot

```
# Order samples to highlight specific ones
```

```
order_spec_labellum <- c(
  which(names(labellum_spec_scaleminmax) == "125"),
  which(names(labellum_spec_scaleminmax) == "126"),
  which(names(labellum_spec_scaleminmax) == "BRAC")
)
```

```
# Reorder columns to place highlighted samples at the end
```

```
columns_labellum <- 1:ncol(labellum_spec_scaleminmax)
```

```
order_spec_labellum <- c(columns_labellum[columns_labellum %notin% order_spec_labellum], order_spec_labellum)
```


```
# Plot the spectra
```

```
plot(labellum_spec_scaleminmax[order_spec_labellum], type = "o",
     col = highlight_colors, main = "Labellum Spectra",
     xlab = "Wavelength (nm)", ylab = "Reflectance (%)")
```

```
# Add a legend
```

```
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 0.8)
```

## Labellum Spectra



## Combine and Save Spectral Plots with Highlighted Parents

```
# Save combined spectra plots with highlighted parental samples
pdf("./results/figures/Combined_Spectra_Bract_Petal_Labellum_Cbracteatus_Clasius_hybrids.pdf", width = 10)
par(mfrow = c(1, 3))
# Increase left margin to provide more space for y-axis labels
par(mar = c(5, 5, 4, 2) + 0.1) # c(bottom, left, top, right)
plot(bract_spec_scaleminmax[order_spec_bract], type = "o", col = highlight_colors,
     main = "Bract spectra", xlab = "Wavelength (nm)", ylab = "Reflectance (%)",
     cex.main = 3, cex.lab = 2.5, cex.axis = 2, lwd = 2)
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 2.5, bty = "n")
plot(petal_spec_scaleminmax[order_spec_petal], type = "o", col = highlight_colors,
     main = "Petal spectra", xlab = "Wavelength (nm)", ylab = "Reflectance (%)",
     cex.main = 3, cex.lab = 2.5, cex.axis = 2, lwd = 2)
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 2.5, bty = "n")
plot(labellum_spec_scaleminmax[order_spec_labellum], type = "o", col = highlight_colors,
     main = "Labellum spectra", xlab = "Wavelength (nm)", ylab = "Reflectance (%)",
     cex.main = 3, cex.lab = 2.5, cex.axis = 2, lwd = 2)
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 2.5, bty = "n")
dev.off()
```

```
## pdf
## 2
```

## Principal component analysis - Bract

```
# opt = 'center' centers the spectra to have a mean reflectance of zero (thus removing brightness as a factor)
# opt = 'bin' bins the spectra into user-defined bins
spec.bin <- procspec(bract_spec_scalemymax, opt = c("bin", "center"))

## processing options applied:
## Centering spectra to a mean of zero
## binned spectra to 21-nm intervals

# Transpose so wavelength are variables for the PCA
spec.bin <- t(spec.bin)

# Names variables as wavelength bins
colnames(spec.bin) <- spec.bin[1, ]
spec.bin <- spec.bin[-1, ] # remove 'wl' row

# Run PCA on the processed spectra data
pca1 <- prcomp(spec.bin, scale. = TRUE)
(summary_pca <- summary(pca1))

## Importance of components:
##
```

	PC1	PC2	PC3	PC4	PC5	PC6	PC7
## Standard deviation	3.3966	2.3243	1.29094	0.78343	0.65511	0.41299	0.32437
## Proportion of Variance	0.5768	0.2701	0.08333	0.03069	0.02146	0.00853	0.00526
## Cumulative Proportion	0.5768	0.8470	0.93030	0.96099	0.98244	0.99097	0.99623


```
##
```

	PC8	PC9	PC10	PC11	PC12	PC13	PC14
## Standard deviation	0.19439	0.13133	0.09227	0.07497	0.04561	0.04302	0.03454
## Proportion of Variance	0.00189	0.00086	0.00043	0.00028	0.00010	0.00009	0.00006
## Cumulative Proportion	0.99812	0.99898	0.99941	0.99969	0.99979	0.99989	0.99995

```
##
```


	PC15	PC16	PC17	PC18	PC19	PC20
## Standard deviation	0.02078	0.01617	0.01300	0.01077	0.006633	0.005973
## Proportion of Variance	0.00002	0.00001	0.00001	0.00001	0.000000	0.000000
## Cumulative Proportion	0.99997	0.99998	0.99999	1.00000	1.000000	1.000000

```
plot(summary_pca$importance[2,])
```



```
# Convert column names (wavelength bins) to numeric values and assign to 'wls'
wls <- as.numeric(colnames(spec.bin))


# Plot loadings of the first principal component (PC1)
plot(pca1$rotation[, 1] ~ wls, type = "l", ylab = "PC1 loading")
abline(h = 0, lty = 2)
```



```
## appears to contrast shorter wavelengths (300-570 nm) with long wavelengths
## (570-700 nm)


# Plot loadings of the second principal component (PC2)
```

```
plot(pca1$rotation[, 2] ~ wls, type = "l", ylab = "PC2 loading")
abline(h = 0, lty = 2)
```



```
## confusing. UV wavelengths (300-400) are correlated with warm colors
## (520-630 nm -- green, yellow, orange, red)
## cool wavelengths (400-520 nm) are correlated with hot colors (630-700 nm -- red)

# Plot loadings of the third principal component (PC3)
plot(pca1$rotation[, 3] ~ wls, type = "l", ylab = "PC3 loading")
abline(h = 0, lty = 2)
```



```
## Confusing. wavelengths 490-610 nm (huge range including most of visible light)
## are contrasted with <490 nm (UV and dark blue/violet) and >610 nm (orange/red)

# Extracting PCA Scores
pca_bract <- data.frame(PC1_bract=pca1$x[,1], PC2_bract=pca1$x[,2], PC3_bract=pca1$x[,3])
```

## Principal component analysis - Petal

```
# opt = 'center' centers the spectra to have a mean reflectance of zero (thus removing brightness as a factor)
# opt = 'bin' bins the spectra into user-defined bins
spec.bin <- procspec(petal_spec_scalemymax, opt = c("bin", "center"))
```

```
## processing options applied:
## Centering spectra to a mean of zero
## binned spectra to 21-nm intervals

# Transpose so wavelength are variables for the PCA
spec.bin <- t(spec.bin)
```

```
# Names variables as wavelength bins
colnames(spec.bin) <- spec.bin[1, ]
spec.bin <- spec.bin[-1, ] # remove 'wl' row
```

```
# Run PCA on the processed spectra data
pca1 <- prcomp(spec.bin, scale. = TRUE)
(summary_pca <- summary(pca1))
```

```
## Importance of components:
##
```

	PC1	PC2	PC3	PC4	PC5	PC6	PC7
## Standard deviation	3.9476	1.6392	0.98410	0.69632	0.35431	0.27714	0.16604
## Proportion of Variance	0.7792	0.1343	0.04842	0.02424	0.00628	0.00384	0.00138
## Cumulative Proportion	0.7792	0.9135	0.96193	0.98617	0.99245	0.99629	0.99767


```
##
```

	PC8	PC9	PC10	PC11	PC12	PC13	PC14
## Standard deviation	0.1345	0.11777	0.08335	0.06943	0.03063	0.02532	0.02234
## Proportion of Variance	0.0009	0.00069	0.00035	0.00024	0.00005	0.00003	0.00002
## Cumulative Proportion	0.9986	0.99927	0.99961	0.99985	0.99990	0.99993	0.99996

```
##
```


	PC15	PC16	PC17	PC18	PC19	PC20
## Standard deviation	0.01865	0.01602	0.01141	0.007871	0.005009	0.001636
## Proportion of Variance	0.00002	0.00001	0.00001	0.000000	0.000000	0.000000
## Cumulative Proportion	0.99998	0.99999	1.00000	1.000000	1.000000	1.000000

```
plot(summary_pca$importance[2,])
```



```
# Convert column names (wavelength bins) to numeric values and assign to 'wls'
wls <- as.numeric(colnames(spec.bin))

# Plot loadings of the first principal component (PC1)
plot(pca1$rotation[, 1] ~ wls, type = "l", ylab = "PC1 loading")
abline(h = 0, lty = 2)
```




```
## appears to contrast short wavelengths (310-510 nm) with long wavelengths
## (510-700 nm)

# Plot loadings of the second principal component (PC2)
```




```
plot(pca1$rotation[, 2] ~ wls, type = "l", ylab = "PC2 loading")
abline(h = 0, lty = 2)
```



*## appears to be associated with the UV range (300-400 nm)*

```
# Plot loadings of the third principal component (PC2)
plot(pca1$rotation[, 3] ~ wls, type = "l", ylab = "PC3 loading")
abline(h = 0, lty = 2)
```



*## appears to be associated with wavelengths 500-550 nm (green)*

```
# Extracting PCA Scores
pca_petal <- data.frame(PC1_petal=pca1$x[,1], PC2_petal=pca1$x[,2], PC3_petal=pca1$x[,3])
```

## Principal component analysis - Labellum

```
# opt = 'center' centers the spectra to have a mean reflectance of zero (thus removing brightness as a factor)
# opt = 'bin' bins the spectra into user-defined bins
spec.bin <- procspec(labellum_spec_scaleminmax, opt = c("bin", "center"))
```

```
## processing options applied:
## Centering spectra to a mean of zero
## binned spectra to 21-nm intervals
# Transpose so wavelength are variables for the PCA
spec.bin <- t(spec.bin)
```

```
# Names variables as wavelength bins
colnames(spec.bin) <- spec.bin[1, ]
spec.bin <- spec.bin[-1, ] # remove 'wl' row
```

```
# Run PCA on the processed spectra data
pca1 <- prcomp(spec.bin, scale. = TRUE)
(summary_pca <- summary(pca1))
```

```
## Importance of components:
##
```

	PC1	PC2	PC3	PC4	PC5	PC6	PC7
## Standard deviation	3.696	1.939	1.33257	0.5831	0.48625	0.39272	0.1896
## Proportion of Variance	0.683	0.188	0.08879	0.0170	0.01182	0.00771	0.0018
## Cumulative Proportion	0.683	0.871	0.95981	0.9768	0.98863	0.99634	0.9981


```
##
```

	PC8	PC9	PC10	PC11	PC12	PC13	PC14
## Standard deviation	0.13245	0.09023	0.08153	0.03977	0.03711	0.02527	0.02280
## Proportion of Variance	0.00088	0.00041	0.00033	0.00008	0.00007	0.00003	0.00003
## Cumulative Proportion	0.99902	0.99942	0.99975	0.99983	0.99990	0.99993	0.99996

```
##
```


	PC15	PC16	PC17	PC18	PC19	PC20
## Standard deviation	0.01880	0.01617	0.009696	0.007808	0.003989	0.001307
## Proportion of Variance	0.00002	0.00001	0.000000	0.000000	0.000000	0.000000
## Cumulative Proportion	0.99998	0.99999	1.000000	1.000000	1.000000	1.000000

```
plot(summary_pca$importance[2,])
```



```
# Convert column names (wavelength bins) to numeric values and assign to 'wls'
wls <- as.numeric(colnames(spec.bin))


# Plot loadings of the first principal component (PC1)
plot(pca1$rotation[, 1] ~ wls, type = "l", ylab = "PC1 loading")
abline(h = 0, lty = 2)
```



```
## appears to contrast shorter wavelengths (300-520 nm) with long wavelengths
## (520-700 nm)

# Plot loadings of the second principal component (PC2)
```


```
plot(pca1$rotation[, 2] ~ wls, type = "l", ylab = "PC2 loading")
abline(h = 0, lty = 2)
```



*## appears to be associated with UV wavelengths (300-390 nm)*

*# Plot loadings of the third principal component (PC3)*

```
plot(pca1$rotation[, 3] ~ wls, type = "l", ylab = "PC3 loading")
abline(h = 0, lty = 2)
```



*## appears to be associated with wavelengths 500-570 nm (green, yellow)*

```
# Extracting PCA Scores
pca_labellum <- data.frame(PC1_labellum=pca1$x[,1], PC2_labellum=pca1$x[,2], PC3_labellum=pca1$x[,3])
```

## Format PC Scores

```
# Replace 'x' with '_' in row names
rownames(pca_bract) <- gsub("x", "_", rownames(pca_bract))
rownames(pca_petal) <- gsub("x", "_", rownames(pca_petal))
rownames(pca_labellum) <- gsub("x", "_", rownames(pca_labellum))

# Convert row names to a column named 'id'
pca_bract <- pca_bract %>% rownames_to_column(var = "id")
pca_petal <- pca_petal %>% rownames_to_column(var = "id")
pca_labellum <- pca_labellum %>% rownames_to_column(var = "id")
```

## Spectral Descriptors

We compute various spectral descriptors to quantify the color properties of the floral tissues.

### Define spectral descriptors

B1: Total brightness B2: Mean brightness B3: Intensity (Rmax) S1U to S1R: Relative contributions of UV, Violet, Blue, Green, Yellow, and Red spectral ranges to total brightness S2: Spectral saturation (Rmax/Rmin) S3: Chroma S4: Spectral purity S5: Chroma S6: Contrast (Rmax - Rmin) S7: Spectral saturation S8: Chroma ((Rmax - Rmin)/B2) S9: Carotenoid chroma ((R700 - R450)/R700) S10: Peak chroma H1 to H5: Hue metrics (e.g., peak wavelength) Note: Some metrics may be sensitive to spectral noise.

## Calculate Spectral Descriptors

### Bract

```
# Calculate spectral descriptors for bract
summary_bract <- summary(bract_spec_scaleminmax)

# Remove S2 due to infinite values
summary_bract <- summary_bract %>% select(-S2)

# Extract metrics for parents
bract125 <- round(summary_bract["125", ], 3)
bract126 <- round(summary_bract["126", ], 3)
bractBRAC <- round(summary_bract["BRAC", ], 3)
```

## Plot Bract Spectral Descriptors Histograms

```
pdf("./results/figures/bract_descriptors_histograms.pdf", width = 14, height = 10)

# Set up plotting area: 4 rows x 6 columns for histograms
par(mfrow = c(4, 6),          # 4 rows, 6 columns
    mar = c(5, 5, 4, 2) + 0.1, # Margins for each plot: bottom, left, top, right
    oma = c(0, 0, 0, 5))      # Outer margins: bottom, left, top, right

# Loop through each metric and plot histogram with parental lines
for (i in 1:ncol(summary_bract)) {
```

```

hist(summary_bract[, i],
      xlab = colnames(summary_bract)[i],
      main = colnames(summary_bract)[i],
      col = "lightgrey",
      border = "white")

# Add vertical lines for parental samples
abline(v = bract125[i], col = 'gold1', lwd = 3)      # C. lasius parent
abline(v = bract126[i], col = 'gold1', lwd = 3)      # C. lasius parent
abline(v = bractBRAC[i], col = 'darkgreen', lwd = 3) # C. bracteatus parent
}

# Allow drawing in the outer margin
par(xpd = TRUE)

plot.new()

# Add a shared legend in the outer right margin
legend("topright",
      inset = c(0, 0), # Adjusts the position of the legend
      legend = c("C. lasius parent", "C. bracteatus parent"),
      col = c("gold1", "darkgreen"),
      lty = 1,          # Line type: solid
      lwd = 3,          # Line width
      cex = 1.5,        # Text size
      bty = "n")        # No box around the legend

# Close the PDF device to save the file
dev.off()

## pdf
## 2

```

## Petal Summary

```

# Calculate summary statistics for petal
summary_petal <- summary(petal_spec_scaleminmax)

# Remove S2 due to infinite values
summary_petal <- summary_petal %>% select(-S2)

# Extract metrics for specific samples
petal125 <- round(summary_petal["125", ], 3)
petal126 <- round(summary_petal["126", ], 3)
petalBRAC <- round(summary_petal["BRAC", ], 3)

```

## Plot Petal Spectral Descriptors Histograms

```

pdf("./results/figures/petal_descriptors_histograms.pdf", width = 14, height = 10)

# Set up plotting area: 4 rows x 6 columns for histograms
par(mfrow = c(4, 6),          # 4 rows, 6 columns
    mar = c(5, 5, 4, 2) + 0.1, # Margins for each plot: bottom, left, top, right

```

```

oma = c(0, 0, 0, 5))      # Outer margins: bottom, left, top, right

# Loop through each metric and plot histogram with parental lines
for (i in 1:ncol(summary_petal)) {
  hist(summary_petal[, i],
        xlab = colnames(summary_petal)[i],
        main = colnames(summary_petal)[i],
        col = "lightgrey",
        border = "white")

  # Add vertical lines for parental samples
  abline(v = petal125[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = petal126[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = petalBRAC[i], col = 'darkgreen', lwd = 3) # C. bracteatus parent
}

# Allow drawing in the outer margin
par(xpd = TRUE)

plot.new()

# Add a shared legend in the outer right margin
legend("topright",
       inset = c(0, 0), # Adjusts the position of the legend
       legend = c("C. lasius parent", "C. bracteatus parent"),
       col = c("gold1", "darkgreen"),
       lty = 1,          # Line type: solid
       lwd = 3,          # Line width
       cex = 1.5,        # Text size
       bty = "n")        # No box around the legend

# Close the PDF device to save the file
dev.off()

## pdf
## 2

```

## Labellum Summary

```

# Calculate summary statistics for labellum
summary_labellum <- summary(labellum_spec_scaleminmax)

# Remove S2 due to infinite values
summary_labellum <- summary_labellum %>% select(-S2)

# Extract metrics for specific samples
labellum125 <- round(summary_labellum["125", ], 3)
labellum126 <- round(summary_labellum["126", ], 3)
labellumBRAC <- round(summary_labellum["BRAC", ], 3)

```

## Plot Labellum Spectral Descriptors Histograms

```
pdf("./results/figures/labellum_descriptors_histograms.pdf", width = 14, height = 10)

# Set up plotting area: 4 rows x 6 columns for histograms
par(mfrow = c(4, 6),          # 4 rows, 6 columns
    mar = c(5, 5, 4, 2) + 0.1, # Margins for each plot: bottom, left, top, right
    oma = c(0, 0, 0, 5))      # Outer margins: bottom, left, top, right

# Loop through each metric and plot histogram with parental lines
for (i in 1:ncol(summary_labellum)) {
  hist(summary_labellum[, i],
       xlab = colnames(summary_labellum)[i],
       main = colnames(summary_labellum)[i],
       col = "lightgrey",
       border = "white")

  # Add vertical lines for parental samples
  abline(v = labellum125[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = labellum126[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = labellumBRAC[i], col = 'darkgreen', lwd = 3) # C. bracteatus parent
}

# Allow drawing in the outer margin
par(xpd = TRUE)

plot.new()

# Add a shared legend in the outer right margin
legend("topright",
      inset = c(0, 0), # Adjusts the position of the legend
      legend = c("C. lasius parent", "C. bracteatus parent"),
      col = c("gold1", "darkgreen"),
      lty = 1,          # Line type: solid
      lwd = 3,          # Line width
      cex = 1.5,        # Text size
      bty = "n")        # No box around the legend

# Close the PDF device to save the file
dev.off()

## pdf
## 2
```

## Data Formatting and Export

### Reformat Rownames

Replace 'x' with '\_' in row names for consistency.

```
# Replace 'x' with '_' in row names
rownames(summary_bract) <- gsub("x", "_", rownames(summary_bract))
rownames(summary_petal) <- gsub("x", "_", rownames(summary_petal))
rownames(summary_labellum) <- gsub("x", "_", rownames(summary_labellum))
```



## Subset and Rename Columns

Select relevant metrics and rename columns to indicate their corresponding floral tissue.

```
# Subset relevant columns based on analysis needs
summary_bract <- summary_bract[, c("S1U", "S1V", "S1B", "S1G", "S1R", "S5", "S9", "H4")]
summary_petal <- summary_petal[, c("B3", "S1U", "S1V", "S1B", "S1Y", "S1R", "S5", "S9", "H4")]
summary_labellum <- summary_labellum[, c("B3", "S1B", "S1Y", "S1R", "S5", "S6", "S9", "H3", "H4")]

# Rename columns to include tissue type
colnames(summary_bract) <- c("S1U_bract", "S1V_bract", "S1B_bract", "S1G_bract",
                             "S1R_bract", "S5_bract", "S9_bract", "H4_bract")
colnames(summary_petal) <- c("B3_petal", "S1U_petal", "S1V_petal", "S1B_petal",
                             "S1Y_petal", "S1R_petal", "S5_petal", "S9_petal", "H4_petal")
colnames(summary_labellum) <- c("B3_labellum", "S1B_labellum", "S1Y_labellum",
                                "S1R_labellum", "S5_labellum", "S6_labellum",
                                "S9_labellum", "H3_labellum", "H4_labellum")
```

## Convert Rownames to a Column

Add the row names as a new column id to facilitate merging.

```
# Convert row names to a column named 'id'
summary_bract <- summary_bract %>% rownames_to_column(var = "id")
summary_petal <- summary_petal %>% rownames_to_column(var = "id")
summary_labellum <- summary_labellum %>% rownames_to_column(var = "id")
```

## UV Analyses

### Spectral Data Processing

#### Convert Data to rspec Objects

The spectral data is converted into rspec objects using the pavo package for further analysis.

```
# Set seed for reproducibility
set.seed(1612217)

# Convert datasets to rspec objects with wavelength limits
bract_spec <- as.rspec(bract, lim = c(300, 400), whichwl = 1)

## The spectral data contain 456 negative value(s),
## which may produce unexpected results if used in models.
## Consider using procspec() to correct them.

petal_spec <- as.rspec(petal, lim = c(300, 400), whichwl = 1)

## The spectral data contain 86 negative value(s),
## which may produce unexpected results if used in models.
## Consider using procspec() to correct them.

labellum_spec <- as.rspec(labellum, lim = c(300, 400), whichwl = 1)

# change column names
colnames(bract_spec) <- gsub("-", "x", colnames(bract_spec))
colnames(petal_spec) <- gsub("-", "x", colnames(petal_spec))
colnames(labellum_spec) <- gsub("-", "x", colnames(labellum_spec))
```

Note: The conversion may produce warnings about negative values in spectral data, which are addressed in subsequent steps.

## Average the Spectra

Aggregate the spectral data by sample names, averaging replicates.

```
# Extract sample names by removing trailing numbers in parentheses
bract_samples <- gsub("\\([0-9]+\\)$", "", names(bract_spec))[-1]
petal_samples <- gsub("\\([0-9]+\\)$", "", names(petal_spec))[-1]
labellum_samples <- gsub("\\([0-9]+\\)$", "", names(labellum_spec))[-1]
```

```
# Verify sample counts
table(bract_samples)
```

```
## bract_samples
##      125      126      39  39x10 39x109 39x110 39x115 39x116 39x117 39x12 39x122
##        2        3        1        2        1        2        2        1        3        2        2
## 39x123 39x125 39x126 39x13 39x130 39x136 39x14 39x15 39x16 39x17 39x2
##        2        2        2        1        3        2        3        2        4        2        2
## 39x21 39x23 39x25 39x27 39x34 39x39 39x4 39x40 39x41 39x44 39x46
##        2        2        2        2        2        2        2        2        2        2        2
## 39x49 39x50 39x51 39x55 39x56 39x57 39x6 39x60 39x65 39x67 39x68
##        2        2        2        2        2        2        2        2        2        2        1
## 39x75 39x77 39x78 39x79 39x8 39x81 39x82 39x86 39x87 39x89 39x92
##        2        2        2        2        1        2        3        1        1        2        2
## 39x93 39x95 39x96 39x98 62x10 62x103 62x105 62x109 62x116 62x119 62x122
##        2        2        2        2        1        2        2        1        1        2        1
## 62x125 62x128 62x129 62x13 62x130 62x131 62x134 62x135 62x136 62x137 62x138
##        1        1        2        2        1        2        1        2        2        1        1
## 62x139 62x14 62x140 62x143 62x144 62x147 62x151 62x152 62x153 62x154 62x157
##        1        1        2        1        2        1        1        3        2        2        2
## 62x158 62x16 62x162 62x167 62x168 62x169 62x17 62x172 62x173 62x175 62x18
##        2        2        2        2        1        1        2        2        2        2        1
## 62x182 62x185 62x188 62x189 62x19 62x190 62x197 62x200 62x206 62x21 62x214
##        1        2        1        1        2        2        2        2        2        2        1
## 62x218 62x219 62x22 62x220 62x225 62x233 62x234 62x240 62x251 62x252 62x258
##        2        2        2        1        2        1        1        2        2        1        1
## 62x261 62x264 62x265 62x267 62x268 62x276 62x282 62x293 62x296 62x300 62x302
##        2        2        1        2        2        1        1        2        1        1        1
## 62x303 62x304 62x305 62x306 62x307 62x308 62x309 62x310 62x313 62x315 62x322
##        2        1        1        1        2        1        2        1        1        1        1
## 62x324 62x327 62x332 62x337 62x338 62x351 62x355 62x359 62x363 62x370 62x5
##        1        1        2        1        2        1        2        2        2        1        1
## 62x57 62x58 62x59 62x60 62x63 62x65 62x66 62x69 62x73 62x74 62x75
##        2        2        2        1        1        1        1        2        2        1        1
## 62x77 62x83 62x87 62x91 62x92 62x94 62x96 BRAC
##        1        2        1        2        2        1        1        2
```

```
table(petal_samples)
```

```
## petal_samples
##      125      126      39  39x10 39x109 39x110 39x115 39x116 39x117 39x12 39x122
##        2        2        1        2        1        2        2        1        3        2        2
## 39x123 39x125 39x126 39x13 39x130 39x136 39x14 39x15 39x16 39x17 39x2
##        2        2        2        1        3        2        3        2        4        2        2
```

```

## 39x21 39x23 39x25 39x27 39x34 39x39 39x4 39x40 39x41 39x44 39x46
##      2      2      2      2      2      2      2      2      2      2      2
## 39x49 39x50 39x51 39x55 39x56 39x57 39x6 39x60 39x65 39x67 39x68
##      2      2      2      2      2      2      2      2      2      2      1
## 39x75 39x77 39x78 39x79 39x8 39x81 39x82 39x86 39x87 39x89 39x92
##      2      2      2      2      1      2      3      1      1      2      2
## 39x93 39x95 39x96 39x98 62x10 62x103 62x105 62x109 62x116 62x119 62x122
##      2      2      2      2      1      2      2      1      1      2      1
## 62x125 62x128 62x129 62x13 62x130 62x131 62x134 62x135 62x136 62x137 62x138
##      1      1      2      2      1      2      1      2      2      1      1
## 62x139 62x14 62x140 62x143 62x144 62x147 62x151 62x152 62x153 62x154 62x157
##      1      1      2      1      2      1      1      3      2      2      2
## 62x158 62x16 62x162 62x167 62x168 62x169 62x17 62x172 62x173 62x175 62x18
##      2      2      2      2      1      1      2      2      2      2      1
## 62x182 62x185 62x188 62x189 62x19 62x190 62x197 62x200 62x206 62x21 62x214
##      1      2      1      1      2      2      2      2      2      2      1
## 62x218 62x219 62x22 62x220 62x225 62x233 62x234 62x240 62x251 62x252 62x258
##      2      2      2      1      2      1      1      2      2      1      1
## 62x261 62x262 62x264 62x265 62x268 62x276 62x282 62x293 62x296 62x300 62x302
##      2      2      2      1      2      1      1      2      1      1      1
## 62x303 62x304 62x305 62x306 62x307 62x308 62x309 62x310 62x313 62x315 62x322
##      2      1      1      1      2      1      2      1      1      1      1
## 62x324 62x327 62x332 62x337 62x338 62x351 62x355 62x359 62x363 62x370 62x5
##      1      1      2      1      2      1      2      2      2      1      1
## 62x57 62x58 62x59 62x60 62x63 62x65 62x66 62x69 62x73 62x74 62x75
##      2      2      2      1      1      1      1      2      2      1      1
## 62x77 62x83 62x87 62x91 62x92 62x94 62x96 BRAC
##      1      2      1      2      2      1      1      2

```

```
table(labellum_samples)
```

```

## labellum_samples
##      125      126      39 39x10 39x109 39x110 39x115 39x116 39x117 39x12 39x122
##      2      2      1      2      1      2      2      1      3      2      2
## 39x123 39x125 39x126 39x13 39x130 39x136 39x14 39x15 39x16 39x17 39x2
##      2      2      2      1      3      2      3      2      4      2      2
## 39x21 39x23 39x25 39x27 39x34 39x39 39x4 39x40 39x41 39x44 39x46
##      2      2      2      2      2      2      2      2      2      2      2
## 39x49 39x50 39x51 39x55 39x56 39x57 39x6 39x60 39x65 39x67 39x68
##      2      2      2      2      2      2      2      2      2      2      1
## 39x75 39x77 39x78 39x79 39x8 39x81 39x82 39x86 39x87 39x89 39x92
##      2      2      2      2      1      2      3      1      1      2      2
## 39x93 39x95 39x96 39x98 62x10 62x103 62x105 62x109 62x116 62x119 62x122
##      2      2      2      2      1      2      2      1      1      2      1
## 62x125 62x128 62x129 62x13 62x130 62x131 62x134 62x135 62x136 62x137 62x138
##      1      1      2      2      1      2      1      2      2      1      1
## 62x139 62x14 62x140 62x143 62x144 62x147 62x151 62x152 62x153 62x154 62x157
##      1      1      2      1      2      1      1      3      2      2      2
## 62x158 62x16 62x162 62x167 62x168 62x169 62x17 62x172 62x173 62x175 62x18
##      2      2      2      2      1      1      2      2      2      2      1
## 62x182 62x185 62x188 62x189 62x19 62x190 62x197 62x200 62x206 62x21 62x214
##      1      2      1      1      2      2      2      2      2      2      1
## 62x218 62x219 62x22 62x220 62x225 62x233 62x234 62x240 62x251 62x252 62x258
##      2      2      2      1      2      1      1      2      2      1      1
## 62x261 62x262 62x264 62x265 62x268 62x276 62x282 62x293 62x296 62x300 62x302

```

```
##      2      2      2      1      2      1      1      2      1      1      1
## 62x303 62x304 62x305 62x306 62x307 62x308 62x309 62x310 62x313 62x315 62x322
##      2      1      1      1      2      1      2      1      1      1      1
## 62x324 62x327 62x332 62x337 62x338 62x351 62x355 62x359 62x363 62x370 62x5
##      1      1      2      2      2      1      2      2      2      1      1
## 62x57 62x58 62x59 62x60 62x63 62x65 62x66 62x69 62x73 62x74 62x75
##      2      2      2      1      1      1      1      2      2      1      1
## 62x77 62x83 62x87 62x91 62x92 62x94 62x96 BRAC
##      1      2      1      2      2      1      1      2

# Aggregate spectra by sample names using mean
bract_spec_avg <- aggspec(bract_spec, by = bract_samples, FUN = mean)
petal_spec_avg <- aggspec(petal_spec, by = petal_samples, FUN = mean)
labellum_spec_avg <- aggspec(labellum_spec, by = labellum_samples, FUN = mean)
```

## Fix Negative Reflectance Values

Negative reflectance values are corrected by adding the minimum reflectance.

```
# Fix negative values by adding the minimum reflectance
bract_spec_avg <- procspec(bract_spec_avg, fixneg = "admin")
```

```
## processing options applied:
## Negative value correction: added min to all reflectance
```

```
petal_spec_avg <- procspec(petal_spec_avg, fixneg = "admin")
```

```
## processing options applied:
## Negative value correction: added min to all reflectance
```

```
labellum_spec_avg <- procspec(labellum_spec_avg, fixneg = "admin")
```


```
## processing options applied:
## Negative value correction: added min to all reflectance
```

## Determine Smoothing Parameter

Use `plotsmooth` to visualize and decide on an appropriate smoothing span.

```
# Plot to determine suitable smoothing span
plotsmooth(bract_spec_avg[,1:7],
  minsmooth = 0.05,
  maxsmooth = 0.5,
  curves = 4,
  ask = FALSE)
```

```
## Warning in simpleLoess(y, x, w, span, degree = degree, parametric = FALSE, :
## k-d tree limited by memory. ncmax= 200
## Warning in simpleLoess(y, x, w, span, degree = degree, parametric = FALSE, :
## k-d tree limited by memory. ncmax= 200
## Warning in simpleLoess(y, x, w, span, degree = degree, parametric = FALSE, :
## k-d tree limited by memory. ncmax= 200
## Warning in simpleLoess(y, x, w, span, degree = degree, parametric = FALSE, :
## k-d tree limited by memory. ncmax= 200
## Warning in simpleLoess(y, x, w, span, degree = degree, parametric = FALSE, :
## k-d tree limited by memory. ncmax= 200
## Warning in simpleLoess(y, x, w, span, degree = degree, parametric = FALSE, :
## k-d tree limited by memory. ncmax= 200
```



Choose a span (e.g., 0.2) based on the plot to balance smoothness and data fidelity.

## Smooth the Spectral Data

Apply smoothing to the spectral data using the chosen span.

```
# Apply smoothing with span = 0.2
bract_spec_sm <- procspec(bract_spec_avg, opt = "smooth", span = 0.2)
```

```
## processing options applied:
## smoothing spectra with a span of 0.2
```

```
petal_spec_sm <- procspec(petal_spec_avg, opt = "smooth", span = 0.2)
```

```
## processing options applied:
## smoothing spectra with a span of 0.2
```

```
labellum_spec_sm <- procspec(labellum_spec_avg, opt = "smooth", span = 0.2)
```

```
## processing options applied:
## smoothing spectra with a span of 0.2
```

## Scale the Spectral Data

Scale the spectral data to different reference points for comparative analysis.

```
# Scale spectra to both minimum and maximum reflectance
bract_spec_scaleminmax_UV <- procspec(bract_spec_sm, opt = c("min", "max"))
```

```
## processing options applied:
## Scaling spectra to a minimum value of zero
```

```
## Scaling spectra to a maximum value of 1
petal_spec_scaleminmax_UV <- procspec(petal_spec_sm, opt = c("min", "max"))

## processing options applied:
## Scaling spectra to a minimum value of zero
## Scaling spectra to a maximum value of 1
labellum_spec_scaleminmax_UV <- procspec(labellum_spec_sm, opt = c("min", "max"))

## processing options applied:
## Scaling spectra to a minimum value of zero
## Scaling spectra to a maximum value of 1
```

## Plot Processed Spectra

Visualize the processed spectral data for each floral tissue, highlighting specific samples.

## Define Common Plotting Parameters

```
# Define a color palette for highlighting specific samples
highlight_colors <- c(rep("lightgrey", 170), "gold1", "gold1", "darkgreen")
```

## Bract Spectra Plot


```
# Order samples to highlight specific ones
order_spec_bract <- c(
  which(names(bract_spec_scaleminmax_UV) == "125"),
  which(names(bract_spec_scaleminmax_UV) == "126"),
  which(names(bract_spec_scaleminmax_UV) == "BRAC")
)

# Reorder columns to place highlighted samples at the end
columns_bract <- 1:ncol(bract_spec_scaleminmax_UV)
order_spec_bract <- c(columns_bract[columns_bract %notin% order_spec_bract], order_spec_bract)

# Plot the spectra
plot(bract_spec_scaleminmax_UV[order_spec_bract], type = "o",
     col = highlight_colors, main = "Bract Spectra",
     xlab = "Wavelength (nm)", ylab = "Reflectance (%)")

# Add a legend
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 0.8)
```

## Bract Spectra



## Petal Spectra Plot


```
# Order samples to highlight specific ones
order_spec_petal <- c(
  which(names(petal_spec_scaleminmax_UV) == "125"),
  which(names(petal_spec_scaleminmax_UV) == "126"),
  which(names(petal_spec_scaleminmax_UV) == "BRAC")
)

# Reorder columns to place highlighted samples at the end
columns_petal <- 1:ncol(petal_spec_scaleminmax_UV)
order_spec_petal <- c(columns_petal[columns_petal %notin% order_spec_petal], order_spec_petal)

# Plot the spectra
plot(petal_spec_scaleminmax_UV[order_spec_petal], type = "o",
     col = highlight_colors, main = "Petal Spectra",
     xlab = "Wavelength (nm)", ylab = "Reflectance (%)")

# Add a legend
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 0.8)
```

## Petal Spectra



## Labellum Spectra Plot

```
# Order samples to highlight specific ones
order_spec_labellum <- c(
  which(names(labellum_spec_scaleminmax_UV) == "125"),
  which(names(labellum_spec_scaleminmax_UV) == "126"),
  which(names(labellum_spec_scaleminmax_UV) == "BRAC")
)


# Reorder columns to place highlighted samples at the end
columns_labellum <- 1:ncol(labellum_spec_scaleminmax_UV)
order_spec_labellum <- c(columns_labellum[columns_labellum %notin% order_spec_labellum], order_spec_labellum)

# Plot the spectra
plot(labellum_spec_scaleminmax_UV[order_spec_labellum], type = "o",
     col = highlight_colors, main = "Labellum Spectra",
     xlab = "Wavelength (nm)", ylab = "Reflectance (%)")

# Add a legend
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 0.8)
```



## Labellum Spectra



## Combine and Save Spectral Plots with Highlighted Parents

```
# Save combined spectra plots with highlighted parental samples
pdf("./results/figures/Combined_UVspectra_Bract_Petal_Labellum_Cbracteatus_Clasius_hybrids.pdf", width = 10, height = 10)
par(mfrow = c(1, 3))
# Increase left margin to provide more space for y-axis labels
par(mar = c(5, 5, 4, 2) + 0.1) # c(bottom, left, top, right)
plot(bract_spec_scaleminmax_UV[order_spec_bract], type = "o", col = highlight_colors,
     main = "Bract spectra", xlab = "Wavelength (nm)", ylab = "Reflectance (%)",
     cex.main = 3, cex.lab = 2.5, cex.axis = 2, lwd = 2)
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 2.5, bty = "n")
plot(petal_spec_scaleminmax_UV[order_spec_petal], type = "o", col = highlight_colors,
     main = "Petal spectra", xlab = "Wavelength (nm)", ylab = "Reflectance (%)",
     cex.main = 3, cex.lab = 2.5, cex.axis = 2, lwd = 2)
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 2.5, bty = "n")
plot(labellum_spec_scaleminmax_UV[order_spec_labellum], type = "o", col = highlight_colors,
     main = "Labellum spectra", xlab = "Wavelength (nm)", ylab = "Reflectance (%)",
     cex.main = 3, cex.lab = 2.5, cex.axis = 2, lwd = 2)
legend("topleft", legend = c("C. bracteatus parent", "C. lasius parent"),
     col = c("darkgreen", "gold1"), lty = 1, cex = 2.5, bty = "n")
dev.off()

## pdf
## 2
```

## Spectral Descriptors

We compute various spectral descriptors to quantify the color properties of the floral tissues.

### Define spectral descriptors

B1: Total brightness B2: Mean brightness B3: Intensity (Rmax) S1U to S1R: Relative contributions of UV, Violet, Blue, Green, Yellow, and Red spectral ranges to total brightness S2: Spectral saturation (Rmax/Rmin) S3: Chroma S4: Spectral purity S5: Chroma S6: Contrast (Rmax - Rmin) S7: Spectral saturation S8: Chroma ((Rmax - Rmin)/B2) S9: Carotenoid chroma ((R700 - R450)/R700) S10: Peak chroma H1 to H5: Hue metrics (e.g., peak wavelength) Note: Some metrics may be sensitive to spectral noise.

### Calculate Spectral Descriptors

#### Bract

```
# Calculate spectral descriptors for bract
summary_bract_UV <- summary(bract_spec_scalemimax_UV)

## Warning: cannot calculate violet chroma; wavelength below 415 nm
## Warning: cannot calculate blue chroma; wavelength range not between 400 and 510
## nm
## Warning: cannot calculate green chroma; wavelength range not between 510 and
## 605 nm
## Warning: cannot calculate yellow chroma; wavelength range not between 550 and
## 625 nm
## Warning: cannot calculate red chroma; wavelength range not between 605 and 700
## nm

# Remove S2 due to infinite values
summary_bract_UV <- summary_bract_UV %>% select(-S2)

# Extract metrics for parents
bract125 <- round(summary_bract_UV["125", ], 3)
bract126 <- round(summary_bract_UV["126", ], 3)
bractBRAC <- round(summary_bract_UV["BRAC", ], 3)
```

#### Plot Bract Spectral Descriptors Histograms

```
pdf("./results/figures/bract_UV_descriptors_histograms.pdf", width = 14, height = 10)

# Set up plotting area: 4 rows x 6 columns for histograms
par(mfrow = c(4, 6),          # 4 rows, 6 columns
    mar = c(5, 5, 4, 2) + 0.1, # Margins for each plot: bottom, left, top, right
    oma = c(0, 0, 0, 5))      # Outer margins: bottom, left, top, right

# Loop through each metric and plot histogram with parental lines
for (i in 1:ncol(summary_bract_UV)) {

  if (!any(!is.na(summary_bract_UV[, i]))) next # Skip columns that are entirely NA

  hist(summary_bract_UV[, i],
        xlab = colnames(summary_bract_UV)[i],
```

```

    main = colnames(summary_bract_UV)[i],
    col = "lightgrey",
    border = "white")

  # Add vertical lines for parental samples
  abline(v = bract125[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = bract126[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = bractBRAC[i], col = 'darkgreen', lwd = 3) # C. bracteatus parent
}

# Allow drawing in the outer margin
par(xpd = TRUE)

plot.new()

# Add a shared legend in the outer right margin
legend("topright",
       inset = c(0, 0), # Adjusts the position of the legend
       legend = c("C. lasius parent", "C. bracteatus parent"),
       col = c("gold1", "darkgreen"),
       lty = 1,          # Line type: solid
       lwd = 3,          # Line width
       cex = 1.5,        # Text size
       bty = "n")        # No box around the legend

# Close the PDF device to save the file
dev.off()

## pdf
## 2

```

## Petal Summary

```

# Calculate summary statistics for petal
summary_petal_UV <- summary(petal_spec_scalemimax_UV)

## Warning: cannot calculate violet chroma; wavelength below 415 nm
## Warning: cannot calculate blue chroma; wavelength range not between 400 and 510
## nm
## Warning: cannot calculate green chroma; wavelength range not between 510 and
## 605 nm
## Warning: cannot calculate yellow chroma; wavelength range not between 550 and
## 625 nm
## Warning: cannot calculate red chroma; wavelength range not between 605 and 700
## nm

# Remove S2 due to infinite values
summary_petal_UV <- summary_petal_UV %>% select(-S2)

# Extract metrics for specific samples
petal125 <- round(summary_petal_UV["125", ], 3)
petal126 <- round(summary_petal_UV["126", ], 3)

```

```
petalBRAC <- round(summary_petal_UV["BRAC", ], 3)
```

## Plot Petal Spectral Descriptors Histograms

```
pdf("./results/figures/petal_UV_descriptors_histograms.pdf", width = 14, height = 10)

# Set up plotting area: 4 rows x 6 columns for histograms
par(mfrow = c(4, 6),          # 4 rows, 6 columns
    mar = c(5, 5, 4, 2) + 0.1, # Margins for each plot: bottom, left, top, right
    oma = c(0, 0, 0, 5))      # Outer margins: bottom, left, top, right

# Loop through each metric and plot histogram with parental lines
for (i in 1:ncol(summary_petal_UV)) {

  if (!any(!is.na(summary_petal_UV[, i]))) next # Skip columns that are entirely NA

  hist(summary_petal_UV[, i],
        xlab = colnames(summary_petal_UV)[i],
        main = colnames(summary_petal_UV)[i],
        col = "lightgrey",
        border = "white")

  # Add vertical lines for parental samples
  abline(v = petal125[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = petal126[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = petalBRAC[i], col = 'darkgreen', lwd = 3) # C. bracteatus parent
}

# Allow drawing in the outer margin
par(xpd = TRUE)

plot.new()

# Add a shared legend in the outer right margin
legend("topright",
       inset = c(0, 0), # Adjusts the position of the legend
       legend = c("C. lasius parent", "C. bracteatus parent"),
       col = c("gold1", "darkgreen"),
       lty = 1,          # Line type: solid
       lwd = 3,          # Line width
       cex = 1.5,        # Text size
       bty = "n")        # No box around the legend

# Close the PDF device to save the file
dev.off()

## pdf
## 2
```

## Labellum Summary

```
# Calculate summary statistics for labellum
summary_labellum_UV <- summary(labellum_spec_scaleminmax_UV)
```

```
## Warning: cannot calculate violet chroma; wavelength below 415 nm
## Warning: cannot calculate blue chroma; wavelength range not between 400 and 510
## nm
## Warning: cannot calculate green chroma; wavelength range not between 510 and
## 605 nm
## Warning: cannot calculate yellow chroma; wavelength range not between 550 and
## 625 nm
## Warning: cannot calculate red chroma; wavelength range not between 605 and 700
## nm
```

```
# Remove S2 due to infinite values
summary_labellum_UV <- summary_labellum_UV %>% select(-S2)

# Extract metrics for specific samples
labellum125 <- round(summary_labellum_UV["125", ], 3)
labellum126 <- round(summary_labellum_UV["126", ], 3)
labellumBRAC <- round(summary_labellum_UV["BRAC", ], 3)
```

## Plot Labellum Spectral Descriptors Histograms

```
pdf("./results/figures/labellum_UV_descriptors_histograms.pdf", width = 14, height = 10)

# Set up plotting area: 4 rows x 6 columns for histograms
par(mfrow = c(4, 6),          # 4 rows, 6 columns
    mar = c(5, 5, 4, 2) + 0.1, # Margins for each plot: bottom, left, top, right
    oma = c(0, 0, 0, 5))      # Outer margins: bottom, left, top, right

# Loop through each metric and plot histogram with parental lines
for (i in 1:ncol(summary_labellum_UV)) {

  if (!any(!is.na(summary_labellum_UV[, i]))) next # Skip columns that are entirely NA

  hist(summary_labellum_UV[, i],
        xlab = colnames(summary_labellum_UV)[i],
        main = colnames(summary_labellum_UV)[i],
        col = "lightgrey",
        border = "white")

  # Add vertical lines for parental samples
  abline(v = labellum125[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = labellum126[i], col = 'gold1', lwd = 3)      # C. lasius parent
  abline(v = labellumBRAC[i], col = 'darkgreen', lwd = 3) # C. bracteatus parent
}

# Allow drawing in the outer margin
par(xpd = TRUE)

plot.new()

# Add a shared legend in the outer right margin
legend("topright",
      inset = c(0, 0), # Adjusts the position of the legend
```

```

legend = c("C. lasius parent", "C. bracteatus parent"),
col = c("gold1", "darkgreen"),
lty = 1,                # Line type: solid
lwd = 3,                # Line width
cex = 1.5,              # Text size
bty = "n")              # No box around the legend

# Close the PDF device to save the file
dev.off()

## pdf
## 2

```

## Data Formatting and Export

### Reformat Rownames

Replace 'x' with '\_' in row names for consistency.

```

# Replace 'x' with '_' in row names
rownames(summary_bract_UV) <- gsub("x", "_", rownames(summary_bract_UV))
rownames(summary_petal_UV) <- gsub("x", "_", rownames(summary_petal_UV))
rownames(summary_labellum_UV) <- gsub("x", "_", rownames(summary_labellum_UV))

```

### Convert Rownames to a Column

Add the row names as a new column id to facilitate merging.

```

# Convert row names to a column named 'id'
summary_petal_UV <- summary_petal_UV %>% rownames_to_column(var = "id")
summary_labellum_UV <- summary_labellum_UV %>% rownames_to_column(var = "id")

```

### Subset and Rename Columns

Select relevant metrics and rename columns to indicate their corresponding floral tissue.

```

# Subset relevant columns based on analysis needs
summary_petal_UV <- summary_petal_UV[, c("id", "H1")]
summary_labellum_UV <- summary_labellum_UV[, c("id", "H1")]

# Rename columns to include tissue type
colnames(summary_petal_UV) <- c("id", "H1_UV_petal")
colnames(summary_labellum_UV) <- c("id", "H1_UV_labellum")

```

## Vision Models

```

# Compute Photoreceptor Quantum Catches for Birds and Bees
## Bract
bract_bird_vis <- vismodel(bract_spec_scalemymax, visual = "avg.uv", relative = TRUE)
bract_bee_vis <- vismodel(bract_spec_scalemymax, visual = "apis", relative = TRUE)


## Petal
petal_bird_vis <- vismodel(petal_spec_scalemymax, visual = "avg.uv", relative = TRUE)
petal_bee_vis <- vismodel(petal_spec_scalemymax, visual = "apis", relative = TRUE)

```


```
## Labellum
labellum_bird_vis <- vismodel(labellum_spec_scaleminmax, visual = "avg.uv", relative = TRUE)
labellum_bee_vis <- vismodel(labellum_spec_scaleminmax, visual = "apis", relative = TRUE)

# Convert Bird Vision Data into a Color Space
bract_bird_colospace <- colspace(bract_bird_vis, space = "auto")
petal_bird_colospace <- colspace(petal_bird_vis, space = "auto")
labellum_bird_colospace <- colspace(labellum_bird_vis, space = "auto")


# Plot the Avian Color Space Representation
plot(bract_bird_colospace, col = spec2rgb(bract_spec_scaleminmax))
```




```
projplot(bract_bird_colospace, pch = 20, col = spec2rgb(bract_spec_scaleminmax))
```




```
plot(petal_bird_colospace, col = spec2rgb(petal_spec_scaleminmax))
```



```
projplot(petal_bird_colospace, pch = 20, col = spec2rgb(petal_spec_scaleminmax))
```




```
plot(labellum_bird_colospace, col = spec2rgb(labellum_spec_scaleminmax))
```




```
projplot(labellum_bird_colospace, pch = 20, col = spec2rgb(labellum_spec_scaleminmax))
```






```
# Convert Bee Vision Data into a Color Space
bract_bee_colospace <- colspace(bract_bee_vis, space = "tri")
petal_bee_colospace <- colspace(petal_bee_vis, space = "tri")
labellum_bee_colospace <- colspace(labellum_bee_vis, space = "tri")


# Plot the Bee Color Space Representation
plot(bract_bee_colospace, col = spec2rgb(bract_spec_scaleminmax))
```



```
plot(petal_bee_colospace, col = spec2rgb(petal_spec_scaleminmax))
```



```
plot(labellum_bee_colospace, col = spec2rgb(labellum_spec_scaleminmax))
```



```
# Replace 'x' with '_' in row names
rownames(bract_bird_colospace) <- gsub("x", "_", rownames(bract_bird_colospace))
rownames(bract_bee_colospace) <- gsub("x", "_", rownames(bract_bee_colospace))

rownames(petal_bird_colospace) <- gsub("x", "_", rownames(petal_bird_colospace))
rownames(petal_bee_colospace) <- gsub("x", "_", rownames(petal_bee_colospace))

rownames(labellum_bird_colospace) <- gsub("x", "_", rownames(labellum_bird_colospace))
rownames(labellum_bee_colospace) <- gsub("x", "_", rownames(labellum_bee_colospace))

# Convert row names to a column named 'id'
bract_bird_colospace <- bract_bird_colospace %>% rownames_to_column(var = "id")
bract_bee_colospace <- bract_bee_colospace %>% rownames_to_column(var = "id")

petal_bird_colospace <- petal_bird_colospace %>% rownames_to_column(var = "id")
petal_bee_colospace <- petal_bee_colospace %>% rownames_to_column(var = "id")

labellum_bird_colospace <- labellum_bird_colospace %>% rownames_to_column(var = "id")
```

```

labellum_bee_colospace <- labellum_bee_colospace %>% rownames_to_column(var = "id")

# Subset relevant columns based on analysis needs
bract_bird_colospace <- bract_bird_colospace[, c("id", "h.theta", "r.vec")]
bract_bee_colospace <- bract_bee_colospace[, c("id", "h.theta", "r.vec")]

petal_bird_colospace <- petal_bird_colospace[, c("id", "h.theta", "r.vec")]
petal_bee_colospace <- petal_bee_colospace[, c("id", "h.theta", "r.vec")]

labellum_bird_colospace <- labellum_bird_colospace[, c("id", "h.theta", "r.vec")]
labellum_bee_colospace <- labellum_bee_colospace[, c("id", "h.theta", "r.vec")]

# Rename columns to include tissue type
colnames(bract_bird_colospace) <- c("id", "h.theta.bird.bract", "r.vec.bird.bract")
colnames(bract_bee_colospace) <- c("id", "h.theta.bee.bract", "r.vec.bee.bract")

colnames(petal_bird_colospace) <- c("id", "h.theta.bird.petal", "r.vec.bird.petal")
colnames(petal_bee_colospace) <- c("id", "h.theta.bee.petal", "r.vec.bee.petal")

colnames(labellum_bird_colospace) <- c("id", "h.theta.bird.labellum", "r.vec.bird.labellum")
colnames(labellum_bee_colospace) <- c("id", "h.theta.bee.labellum", "r.vec.bee.labellum")

```

## Merge Dataframes

```

# Merge all summaries by 'id'
joined_df <- pca_bract %>%
  full_join(pca_petal, by = "id") %>%
  full_join(pca_labellum, by = "id") %>%
  full_join(summary_bract, by = "id") %>%
  full_join(summary_petal, by = "id") %>%
  full_join(summary_labellum, by = "id") %>%
  full_join(summary_petal_UV, by = "id") %>%
  full_join(summary_labellum_UV, by = "id") %>%
  full_join(bract_bird_colospace, by = "id") %>%
  full_join(bract_bee_colospace, by = "id") %>%
  full_join(petal_bird_colospace, by = "id") %>%
  full_join(petal_bee_colospace, by = "id") %>%
  full_join(labellum_bird_colospace, by = "id") %>%
  full_join(labellum_bee_colospace, by = "id")

```

## Export Summary Descriptors to CSV

Save the combined summary descriptors to a CSV file for further analysis or reporting.

```

# Write the combined summary dataframe to a CSV file
write.csv(joined_df, "./results/processed_data/color_traits.csv",
          quote = FALSE, row.names = FALSE)

```